

## ■ Application example for Power transforming equipment

No power supply, no wiring required. Just affix the label to the areas to be monitored temperature.

